




Point	Easting	Northing	Latitude	Longitude	LAT_DD	LON_DD
CNE	153303.72	861872.56	57° 34.757'N	6° 7.701'W	57.579279	-6.128346
CSE	153179.69	861408.86	57° 34.504'N	6° 7.797'W	57.575057	-6.129943
CSW	153025.13	861450.2	57° 34.521'N	6° 7.954'W	57.575343	-6.132562
CNW	153149.15	861913.9	57° 34.774'N	6° 7.858'W	57.579565	-6.130965
CMID	153163.45	861661.13	57° 34.639'N	6° 7.829'W	57.577308	-6.13047
CRLNW	153080.17	862241.64	57° 34.948'N	6° 7.947'W	57.582463	-6.13245
CRLNE	153669.45	862084.02	57° 34.883'N	6° 7.348'W	57.581373	-6.12246
CRLSE	153390.39	861040.7	57° 34.313'N	6° 7.564'W	57.571874	-6.126055
CRLSW	152801.11	861198.32	57° 34.378'N	6° 8.163'W	57.572964	-6.136042
CRLCENT	153235.28	861641.17	57° 34.631'N	6° 7.756'W	57.577169	-6.129252
CFBM	153046.64	861694.79	57° 34.653'N	6° 7.948'W	57.577546	-6.132452