


This is the Seawater Abstraction Assembly Point, being 48m from the start of the Diffuser Assembly, which is at the inside point of this North Jetty



This is the North Jetty.  
Diffuser Assembly will be 4.5m from the point of the Jetty,  
with a spread of 25.5m

DIFFUSER

07.07.2021 15:33

